




Schreibtische der H-Serie / Q-Serie


Assembly instruction : desk range H.. / Q..



<p>HS08, HS12, HS16</p>	<p>QS08, QS12, QS16</p>
<p>HS18</p>	<p>QS18</p>
<p>HS18</p>	<p>QS18</p>
<p>HS82</p>	<p>QS82</p>



Schreibtische der H-Serie / Q-Serie




Beipack :
fitting:
8 -10 x (A)
(4.5x 55)

8-10 x (A)

41 mm

41 mm

41 mm




Beipack :
fitting:
11 x (A)
(4.5x 55)

11 x (A)

41 mm

41 mm

41 mm



Beipack :
fitting:
12 x (A)
(4.5x 55)


Bei QS21:
+
4 x (B)
(4.5 x 25)

12 x (A)

41 mm

41 mm

41 mm



Beipack :
fitting:
13 x (A)
(4.5x 55)

13 x (A)

41 mm

41 mm

41 mm

Montageanleitung : Verkettungs - Anbauplatten

Assembly instruction : Cornerlink, deskend extension

